

# IMPORTANT PLEASE READ

## **Cordless Cellular/Pleated Shades Operating Instructions**

Thank you for purchasing a cordless Cellular or Pleated Shade. This lift system eliminates the need for cords and provides a more attractive appearance. Cordless shades are the safest window shade alternative; ideal for homes with children and pets.

**To maintain optimum performance of your cordless shade, we recommend you operate your shade daily.**

In the event your shade is in the lowered position for an extended period of time, the fabric of the shade may relax and resist lifting. This is a natural occurrence with fabric shades. When lifting the shade after an extended period of time, you may notice the fabric billowing (puff out) toward you. This is temporary and can be corrected by completely raising the shade and then operating the shade several times. This will allow the fabric to go back to its natural state, and your cordless shade will then operate as designed.

If the shade has been in the fully raised position for an extended period of time, the shade may have the tendency to “bounce up” above the desired length of the shade. This is temporary and can be corrected by completely lowering the shade and then operating the shade several times. This will allow the fabric to go back to its natural state, and your cordless shade will then operate as designed.



If the shade is less than 48" in width (52" Pleated), always lift the shade from the middle of the rail, using a handle is highly recommended. This will help eliminate any unevenness that may occur. If the shade is over 48" in width (52" Pleated), use 2 handles and space them evenly apart. For very wide shades, place handles as far apart as you comfortably can reach, use both hands to lift the shade. This will prevent bowing of the rails or raising and lowering unevenly.

Bracket placement is essential to the performance of cordless Cellular/Pleated Shades. Please follow the installation instructions in your manual closely.