

Wood Cornice Measuring Instructions.

Measure the width of the window opening or outside mounted window treatment that will be covered by the cornice.

Add at least 2" to the measured width to provide clearance. Your cornice will need to be mounted approximately 1 ½" above the window opening or window treatment already installed.

The Width you order will be the width of inside face of the cornice, and the "outside face" will be 2" wider than the ordered width.

