

Cornice Measuring Instructions

Measure the width of the window opening or outside mounted window treatment that will cover the cornice. Add at least 2" to the measured width to provide clearance.

Your cornice will need to be mounted approximately 1 ½" above the window opening or window treatment already installed.

The crown design will make the total width 7" greater than the measurement you give. Do not add this amount when submitting measurements; simply make sure there is space on both sides of your window to allow for this.

