


INSTALLATION INSTRUCTIONS – ECONOMY CELLULAR SHADES

Notes:

- Save packaging until shade is installed and working to your satisfaction.
- Lift mechanism should not be operated prior to installation.
- Shades are shipped with the appropriate number of brackets and hardware.
- For drywall, metal, or special cases, you may need wall anchors (not provided).
- Due to compression in shipping, the shade may initially hang slightly short. After installation, stretch the shade by running your hands over the fabric from top to bottom; the shade will stretch to desired length.


Components:




- | | |
|------------------------|--------------------------------|
| 1. Headrail | 8. Plastic washer |
| 2. Bottomrail | 9. Cord lock |
| 3. Mounting bracket | 10. Cord |
| 4. Rail end cap | 11. Child safety device |
| 5. Bottomrail end cap | 12. Pulling cord |
| 6. Cord guide | 13. Tassel |
| 7. Rail insert in coil | 14. Screw for mounting bracket |

Step 1: Mount the brackets.

- Brackets can be used for **Inside Mount** (inside the window frame, secured upwards into the frame) or **Outside Mount** (secured into the wall above the window frame). Notice the label on the shade to see which you've ordered.
- For an **Inside Mount**, place each bracket $\frac{1}{4}$ " from the front edge of your window frame. Mark the placement using a pencil, using only the single hole in the top of the bracket. Secure the brackets using the screws provided.



- For an **Outside Mount**, place each bracket in the desired location on the wall. Mark the placement using a pencil, using the 2 holes in the side of the bracket. Secure the brackets using the screws provided.




IMPORTANT: Make sure the brackets are all in line and level.

Number of brackets included with your shade:

Width	# of Brackets
0 - 38"	2
38" - 59"	3
59" +	4

Step 2: Install the shade.

- a. Hold the shade up near the brackets and insert the front dip of the bracket into the front groove of the rail.
- b. Make sure the shade is centered in the window opening.
- c. Push the rail back and up until the back clips of the bracket are inserted in the back groove of the rail. You will feel a snap.



To remove the shade, reverse the procedure.

Cordlock Operation:

To raise or lock shade, pull the cord down and away from the shade. To lower or release the shade, pull cord downward to release the lock.

Cleaning and Care:

Regular dusting with a feather duster or vacuum cleaner brush is recommended. You can use a damp sponge and mild detergent for stains.

Child Safety Device:

This device prevents strangulation and entanglement by detaching the cord in response to pressure.



WARNING



Window Blind Cord Can
STRANGLE Your Child

- Children can strangle in the loop above the cord bead.
- Children can climb furniture to reach cords.
- Move crib and furniture away.
- Shorten cords to prevent reach.
- Keep cords separate - Twisted or knotted cords can create a loop.
- Keep all cords out of children's reach.


INSTALLATION INSTRUCTIONS – CORDLESS ECONOMY CELLULAR SHADES

Notes:


- Save packaging until shade is installed and working to your satisfaction. Please be careful not to throw away the small clear plastic handles.
- Shades are shipped with the appropriate number of brackets and hardware
- For drywall, metal, or special cases, you may need wall anchors (not provided).
- Due to compression in shipping, the shade may initially hang slightly short. After installation, stretch the shade by running your hands over the fabric from top to bottom; the shade will stretch to desired length.

Step 1: Mount the brackets.

- Brackets can be used for **Inside Mount** (inside the window frame, secured upwards into the frame) or **Outside Mount** (secured into the wall above the window frame). Notice the label on the shade to see which you've ordered.
- For an **Inside Mount**, place each bracket $\frac{1}{4}$ " from the front edge of your window frame. Mark the placement using a pencil, using only the single hole in the top of the bracket. Secure the brackets using the screws provided.



- For an **Outside Mount**, place each bracket in the desired location on the wall. Mark the placement using a pencil, using the 2 holes in the side of the bracket. Secure the brackets using the screws provided.




IMPORTANT: Make sure the brackets are all in line and level.

Number of brackets included with your shade:

Width	# of Brackets
0 - 38"	2
38" - 59"	3
59" +	4

Step 2: Install the shade.

- Hold the shade up near the brackets and insert the front dip of the bracket into the front groove of the rail.
- Make sure the shade is centered in the window opening.
- Push the rail back and up until the back clips of the bracket are inserted in the back groove of the rail. You will feel a snap.



To remove the shade, reverse the procedure.

Cleaning and Care:

Regular dusting with a feather duster or vacuum cleaner brush is recommended. You can use a damp sponge and mild detergent for stains.