


N301168-2  
65101-11913-B

## Installation Instructions Honeycomb Shades

Cordloop & Cordloop TD & Cordloop Day &  
Night & SmartRelease Cordloop



### Getting Started

Remove shade from package. Save packaging until shade is installed and working to your satisfaction.



#### Tools:

- Power drill
- Tape measure
- Screwdriver
- Level
- Pencil

#### Installation Screws

Surface	Fastener
Wood	#8 1 1/4" Screws (Provided)
	M4x48mm screws (Provided)
	#6 3/4" screws (Provided)
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provided)
Metal	Sheet Metal Screws (Not Provided)

#### Check Components/Hardware:



Installation Bracket



Hold Down Brackets (Optional)

#### Hardware Standard Quantity


Order Width (X)	$X \leq 39"$	$39" < X \leq 66"$	$66" < X \leq 93"$	$93" < X \leq 120"$
Installation Bracket	2	3	4	5

Order Width (X)	$X \leq 39"$	$39" < X \leq 66"$	$66" < X \leq 93"$	$93" < X \leq 120"$
1 1/4" Screw for Cord Tensioner	2	2	2	2
1 1/4" Screw for Installation Bracket	4	6	8	10
3/4" Screw for Hold Down Bracket (Optional)	4	4	4	4
2" Screw for Installation Bracket with spacer block (Optional)	4	6	8	10
Hold Down Bracket (Optional)	2	2	2	2
Spacer Block (Optional)	1pc to extend distance 3/8" 2pcs to extend distance 11/16"			

**Note: Optional flat head screw included. Use as needed.**


#### Step 1: Bracket Installation

Measure 3" from both ends of the headrail. Mark bracket location on the mounting surface.




#### Inside Mount

•Use two #8 1 1/4" mounting screws to secure brackets. Use wall anchors for drywall or plaster wall.




•For 3/8" Single, 1/2" Double, 9/16" Single, 3/4" Single, allocate a min. distance of 1/16" from wall to the front of brackets as left drawing shows.




•For 1 1/4" Single, 3/4" Double, allocate a min. distance of 1/32" from wall to the front of brackets as left drawing shows.

#### Outside Mount

•Use two #8 1 1/4" mounting screws to attach each bracket. Use wall anchors for drywall or plaster wall.




•For 3/8" Single, 1/2" Double, 9/16" Single, 3/4" Single allocate a min. distance of 1/32" from wall to the bottom of brackets as left drawing shows.



•For 1 1/4" Single, 3/4" Double, allocate a min. distance of L2 from wall to the bottom of brackets as left drawing shows.  
 $0 \leq L2 \leq 1/4"$

•\* For shallow mount, use the provided flat head screws to secure the bracket as shown in the image below.




#### Step 2: Shade Installation

Position the headrail at an angle so that it hooks into the front of the bracket. Then push upward to snap the headrail into the brackets.

⚠ For proper installation, start by attaching the front of the rail to the bracket and ensure to stick right in place.

•For easier installation, lower the middle rail of CordLoop TD away from the headrail before installing the headrail.


*Note: You will hear a click sound once the head rail is properly secured.*




#### Step 3: Cord Tensioner Installation

⚠ Both Inside mount & Outside mount Cord Loop cord tensioners will be provided with the shade regardless of the mount type. The Cord Loop cord tensioner pre-attached on the cord will be determined by order mount type. You may find the other type of cord tensioner in the hardware box. Please refer to the installation instructions in the hardware box to find the steps for installing and exchanging the IM & OM Cord Tensioners.

##### IM Cord Loop Cord Tensioner



##### OM Cord Loop Cord Tensioner




⚠ For IM, to avoid the Cord Tensioner interfering with the bottom rail and fabric, please install the Cord Tensioner a bit forward. Do not install the Cord Tensioner aligning to the head rail.

★ **Congratulations! You have finished installing the shade.**

#### How to Install Hold Down Brackets (optional)


##### A. For Hold Down Brackets.

•Use #6 3/4" screw to secure each bracket.




##### B. For Magnetic Hold Down

Use M3x15mm screw to secure the magnet catch at the below location. Make sure the magnet catch aligns with the pre-installed magnet on shade bottom rail.




## Shade Operation


● **For Cordloop**, Pull cord to operate shade. Cord Tensioner must be fully tightened prior to operating the shade.




● **For Cordloop TD & Cordloop Day & Night**, Cord Tensioner must be fully tightened prior to operating the shade. Original status is as below picture.




Pull the control cord as the arrow direction in below picture. The middle rail & bottom rail will go down together as below.




Pull the control cord as the arrow shows. The bottom rail will stop once it reaches the bottom. The middle rail will raise to the top.




The middle rail will stop when it meets the headrail.




Pull the control cord as below arrow direction, the middle rail will go down.



Pull the control cord as the arrow shows. The middle rail will lower. Once the middle rail reaches the bottom, the middle & bottom rail will raise up together.




The middle rail & bottom rail will stop when they meet the headrail.




● **For SmartRelease Cordloop**, Cord Tensioner must be fully tightened prior to

operating the shade. Pull the front control cord to let the shade go up.




Pulling the back control cord will allow the shade to fully lower automatically. To stop the shade from lowering, gently pull the front cord.

Note that the control cord should not be too tight during installation, and there should be no obstructions when the shade is lowering. Please do not play with the bottom rail or the control cord as this may cause damage to the shade.




## Remove the Cord Tensioner

OM: Hold the tab up with a small screwdriver and slide the cord tensioner out of its base.




IM: Slide the cord tensioner out from its base.



## Shade Removal

- Fully raise the shade.
- Gently pry the bracket off the headrail with a flat screwdriver.
- Remove the shade.



## Note


- Keep away from heat, sparks and open flame.
- Larger windows may require two people for installation.
- During installation, firmly support the shade to avoid its falling down. Failure to do so may result in damage to the shade or injury to oneself.
- Only operate shade with the pull cord.
- To ensure child safety, install cord cleat and tighten up any loose cords after the shade is installed

## Cleaning

Routine cleaning will help maintain the beauty of your shade. The shade can be cleaned by using a soft brush, vacuumed with a low suction hand-held vacuum, cleaned ultrasonically (specify that a mild solution must be used and that the headrail should never be immersed in liquid). Spot cleaning is not recommended, but if necessary, dampen a clean cloth with solution of warm water and mild detergent to dab the spot until it's gone (do not rub!)

## Troubleshooting

Problem	Solution
For Woven fabrics, repeated rubbing or where it comes into contact with the window edge may cause the fabric edges to fray slightly over time.	To remedy, use a pair of fabric scissors to gently trim the fraying.




*Some options listed may not be applicable.*

## Installation Instructions

### Honeycomb Shades

**Cordless, Cordless TDBU, Cordless Day & Night**



Handle

Hold Down bracket  
(Optional)


### Hardware Standard Quantity

Order Width (X)	$X \leq 43"$	$43" < X \leq 72"$	$72" < X \leq 101"$	$X > 101"$
Installation Bracket	2	3	4	5
Handle	1pc for $X \leq 72"$ , 2pcs for $X > 72"$ (Cordless) 2pcs for $X \leq 72"$ , 4pcs for $X > 72"$ (Cordless TDBU & Day & Night)			
1 1/4" Screw for Installation Bracket	4	6	8	10
Hold Down Bracket (Optional)	2	2	2	2
Spacer Block (Optional)	1pc to extend distance 3/8" 2pcs to extend distance 11/16"			
2" Screw for Installation Bracket with Spacer Block (Optional)	4	6	8	10
3/4" Screw for Hold Down Bracket (Optional)	4	4	4	4


*Note: Optional flat head screws included.  
Use as needed.*

### Step 1: Bracket Installation

For shade width  $> 20"$ , measure 7" from both ends of the head rail. Mark the bracket location on the mounting surface.




For shade width  $\leq 20"$ , space each bracket evenly. Mark the bracket location on the mounting surface.





### Side Mount

•Use two 1 1/4" mounting screws to secure brackets. Use wall anchors for drywall or plaster wall.  
Allocate a min. distance of 1/16" from wall to the front of brackets.




**For 3/8" Single, 3/4" Single & 1/2" Double, 3/4" Double & 1 1/4" Single:**  
Cordless, Cordless TDBU, Cordless Day & Night



3/4" Single & 1/2" Double  
Cordless, place brackets  
and align with the wall.


### Outside Mount

•Use two #8 1 1/4" mounting screws to secure brackets. Use wall anchors for drywall or plaster wall.




•For 3/8" Single, 9/16" Single, 3/4" Single & 1/2" Double, Cordless, Cordless TDBU, Cordless Day & Night

•Allocate a min. distance of 1/16" between the end of brackets and the top of window frame.




•For 3/4" Double & 1 1/4" Single, Cordless, Cordless TDBU, Cordless Day & Night  
Allocate a min. distance of L2 between the end of the brackets and the top of the window frame.

(0 ≤ L2 ≤ 1/4")



\* For shallow mounting, use 1pc or 2pcs of flat head screw to secure the bracket as below.




### Step 2: Shade Installation

•Position headrail at an angle so that it is hooked to the front of the bracket. Then push it upward to snap into the brackets.

⚠ For proper installation, start by attaching the front of the rail to the bracket and ensure to stick right in place.


For easier installation, lower the middle rail of cordless TDBU away from the headrail before installing the headrail.

**Note: You will hear a click sound once the head rail is properly secured.**



### Step 3: How to Install Shade Handle

⚠ For order width  $> 72"$ , the distance between the 2 handles should be 48" as below.



### Getting Started

Remove shade from package. Save packaging until shade is installed and working to your satisfaction.

#### Tools:


- Level
- Measuring Tape
- Pencil
- Power drill  
(1/4" hex driver and drill bit)
- Screwdriver




You will need to use the following fasteners for your particular mounting surface.

Surface	Fastener
Wood	#8 1 1/4" Screws (Provided) #6 3/4" screws
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provided)
Metal	Sheet Metal Screws (Not Provided)


### Check Components/Hardware:



Cordless  
(3/8" Single, 9/16" Single)



Cordless  
(3/4" Single, 1/2" Double)



Cordless TDBU/DNN  
(3/8" Single, 9/16" Single,  
3/4" Single, 1/2" Double)




Cordless/  
Cordless TDBU/DNN  
(3/4" Double, 1 1/4" Single)

Installation Bracket




### Middle Rail:

Position the handle at an angle so that it is hooked to the rib at the top of the bottom rail. Then push the handle downward to snap into place. You will hear a loud click sound once the handle is properly secured.



### Bottom Rail:

Position the handle at angle so that it is hooked to the rib on the bottom of the bottom rail. Then push the handle upward to snap into place. You will hear a loud click sound once the handle is properly secured.




★ **Congratulations! You have finished installing the shade.**

### How to Remove Shade Handle


Use a flat head screwdriver to remove both hooked parts. When the hooked parts are loosened, the handle will easily come off.

(To avoid scratching the rail with the screwdriver, please put a piece of adhesive tape on the head of the screwdriver before removing the handle from the rail.)


### Middle Rail



### Bottom Rail



### Shade Operation



**To lower the shade**, gently pull down the shade by the bottom rail handle and stop at the desired location.

**For TDBU & Day & Night**, pull down the bottom rail first before lowering the middle rail.

**To raise the shade**, gently raise the shade by the bottom rail handle to desired height.


**For TDBU & Day & Night**, if the shade will not lift, first lower the middle rail completely to the bottom rail. Raise both up together.

⚠ Do not grasp the rail unevenly. Always lower or raise the shade in the middle or use even pressure with both hands to operate both handles on the rail.


### How to Install Hold Down (optional)

### A. For Hold Down Brackets.

Use #6 3/4" screw to secure each bracket.




Use M3x15mm screw to secure the magnet catch at the below location. Make sure the magnet catch align with the pre-installed magnet on shade bottom rail.



### Remove the Shade

**For cordless**, fully raise the shade.

**For TDBU / Day & Night**, Lower the middle rail. Gently pry the bracket off the head rail with a flat screwdriver as below picture. Remove the shade.




### Cleaning the Shade

Routine cleaning will help maintain the beauty of your shade. The shade can be cleaned by using a soft brush, vacuumed with a low suction hand-held vacuum, cleaned ultrasonically (specify that a mild solution must be used and that the head rail should

never be immersed in liquid). Spot cleaning is not recommended, but if necessary, dampen a clean cloth with a solution of warm water and mild detergent to dab the spot until it's gone (do not rub!).

### Troubleshooting

Problem	Solution
The shade will not snap into the mounting brackets	Check if mounting brackets are aligned. Refer to below drawing. 
The shade will not lift	Gently pull down on the bottom rail to reactivate the cordless mechanism. Repeat if necessary. For TDBU & Day&Night, pull the midrail down fully to the bottom first. Then raise the bottom rail and middle rail up together. Check if all brackets are locked in place. Refer to below drawing. 
The shade stack up unevenly	Lower the shade completely. Then raise it up to correct it. Repeat if necessary.



*Some options listed may not be applicable.*




N301182-6  
65101-11920-F

# Installation Instructions

## Honeycomb Shades

Cordless & Cordless TDBU for Woven Colors



### Getting Started

Remove shade from package. Save packaging until shade is installed and working to your satisfaction.

#### Tools:


- Level
- Measuring Tape
- Pencil
- Power drill
- (1/4" hex driver and drill bit)
- Screwdriver



You will need to use the following fasteners for your particular mounting surface.

Surface	Fastener
Wood	#8 1 1/4" Screws (Provided) #6 3/4" screws
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provided)
Metal	Sheet Metal Screws (Not Provided)

### Check Components/Hardware:



### Hardware Standard Quantity

For Cordless:

Order Width (X)	X ≤ 39"	39" < X ≤ 66"	66" < X ≤ 86"
Installation Bracket	2	3	4
Handle	1pc for X ≤ 72" 2pcs for X > 72"		
1 1/4" Screw for Installation Bracket	4	6	8
Hold Down Bracket (Optional)	2	2	2
Spacer Block (Optional)	1pc to extend distance 3/8" 2pcs to extend distance 11/16"		
2" Screw for Installation Bracket with Spacer Block (Optional)	4	6	8
3/4" Screw for Hold Down Bracket (Optional)	4	4	4


For Cordless TDBU:

Order Width (X)	X ≤ 39"	39" < X ≤ 66"	66" < X ≤ 78"
Installation Bracket	2	3	4
Handle	2pcs for X ≤ 72" 4pcs for X > 72"		
1 1/4" Screw for Installation Bracket	4	6	8
Hold Down Bracket (Optional)	2	2	2
Spacer Block (Optional)	1pc for extend distance 3/8" 2pcs for extend distance 11/16"		
2" Screw for Installation Bracket with Spacer Block (Optional)	4	6	8
3/4" Screw for Hold Down Bracket (Optional)	4	4	4

Note: Optional flat head screws included.  
Use as needed.

### Step 1: Bracket Installation


- Measure 5" from both ends of the headrail. Mark the bracket location on the mounting surface.



### Inside Mount:

Use two 1 1/4" mounting screws to secure brackets.  
Use wall anchors for drywall or plaster wall.


Place brackets and align with the wall.




### Outside Mount:

Use two 1 1/4" mounting screws to secure brackets.  
Use wall anchors for drywall or plaster wall.

Allocate a min. distance of 3/16" between the end of the brackets and the top of the window frame.




\* For shallow mounting, use a flat head screw to secure the bracket at 45°.




### Step 2: Shade Installation

- Position the headrail at an angle so that it hooks into the front of the bracket. Then push upward to snap the headrail into the bracket.
- ▲ For proper installation, start by attaching the front of the rail to the bracket and ensure to stick right in place.
- Note: You will hear a click sound once the head rail is properly secured..
- For easier installation, lower the middle rail of cordless TDBU away from the headrail before installing the headrail.



### Step 3: How to Install Shade Handle

Hook the top part of the handle onto the rail rib. Push the handle downward so it clips to the bottom of the rail. You will hear a loud click sound once the handle is properly secured.




★ Congratulations! You have finished installing the shade.

### How to Uninstall Shade Handle


▲ For order width > 72", the distance between the 2 handles should be 48" as below.



Use a flat head screwdriver to remove the handle from the bottom of the rail.  
(To avoid scratching the rail with the screwdriver, please put a piece of adhesive tape on the head of the screwdriver before removing the handle from the rail.)



## Shade Operation



**To lower the shade**, gently pull down the shade by the bottom rail handle and stop at the desired location.

**For TDBU**, pull down the bottom rail first before lowering the middle rail.

**To raise the shade**, gently raise the shade by the bottom rail handle to desired height.


**For TDBU**, if the shade will not lift, pull the middle rail down fully to the bottom first and then raise up bottom rail together with middle rail.

⚠ Do not grasp the rail unevenly. Always lower or raise the shade in the middle, or use even pressure with both hands to operate both handles on the rail.

## How to Install Hold Down (optional)


### A. For Hold Down Brackets

Use #6 3/4" screw to secure each bracket.



### B. For Magnetic Hold Down

Use M3x15mm screw to secure the magnet catch at the below location. Make sure the magnet catch aligns with the pre-installed magnet on shade bottom rail.




## Shade Removal

For cordless, fully raise the shade.

For TDBU, lower the middle rail.

Gently pry the bracket off the headrail with a flat screwdriver as pictured below.


Remove the shade.





## Cleaning the Shade

Routine cleaning will help maintain the beauty of your shade. The shade can be cleaned by using a soft brush, vacuumed with a low suction hand-held vacuum, cleaned ultrasonically (specify that a mild solution must be used and that the headrail should never be immersed in liquid). Spot cleaning is not recommended, but if necessary, dampen a clean cloth with a solution of warm water and mild detergent to dab the spot until it's gone (do not rub!).

## Troubleshooting


Problem	Solution
The shade will not snap into the mounting brackets.	Check if mounting brackets are aligned. Refer to below drawing. 
The shade will not lift.	Gently pull down on the bottom rail to reactivate the cordless mechanism. Repeat if necessary. For TDBU, pull the middle rail

Problem	Solution
	down fully to the bottom first. Then raise the bottom rail and middle rail up together. Check if all brackets are locked in place. Refer to below drawing. 
The shade stacks up unevenly.	Lower the shade completely, and then raise it up to correct it. Repeat if necessary.
For Woven fabrics, repeated rubbing or where it comes into contact with the window edge may cause the fabric edges to fray slightly over time.	To remedy, use a pair of fabric scissors to gently trim the fraying.




*Some options listed may not be applicable.*

**N301184-1**  
**65101-11922-A**  
**Installation Instructions**  
**Honeycomb Shades**  
**ClearFit™**



With Rail Cover



Without Rail Cover

## Getting Started





Remove the shade from the package. Save the packaging until the shade is installed and working to your satisfaction.

### Tools Needed:

- Power drill and drill bit
- Measuring tape
- Screwdriver
- Level
- Pencil



You will need to use the following fasteners for your particular mounting surface.

Surface	Fastener
Wood	M3.5x25mm Screws (Provided) 
	M3.8x38mm 
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provided) 
Metal	Sheet Metal Screws (Not Provided) 

## Check Components/Hardware:



Handle Base (Pre-Installed)



Handle

## Hardware Standard Quantity

Order Width (X)	X ≤ 50"	X > 50"
Handle	2	4
Cord Equalizer Housing Base(with Rail Cover)	2	
Cord Equalizer Housing Base(without Rail Cover)	4	


Order Width (X)	X ≤ 50"	X > 50"
L Bracket (for 3/8" Single, Outside Mount) (with Rail Cover)	2	N/A
L Bracket (for 3/8" Single, Outside Mount) (without Rail Cover)	4	N/A
L Bracket for windows with marble sill (Optional)	2	
L bracket (for 3/4" Single, 1/2" Double & 9/16" Single Outside Mount) (with Rail Cover)	2	
L bracket (for 3/4" Single, 1/2" Double & 9/16" Single, Outside Mount) (without Rail Cover)	8.5" < X ≤ 40", 4 40" < X ≤ 52", 5 52" < X ≤ 65", 6 65" < X ≤ 72", 7	
M3.5x25mm Screw (for Base, 3/8" Single, Inside Mount) (with Rail Cover)	8.5" < X ≤ 40", 4 40" < X ≤ 50", 5	N/A
M3.5x25mm Screw (for Base, 3/8" Single, 3/4" Single, 1/2" Double & 9/16" Single Inside Mount) (without Rail Cover)	4	
M3.5x25mm Screw (for Base, 3/4" Single, 1/2" Double & 9/16" Single, Inside Mount) (with Rail Cover)	8.5" < X ≤ 40", 4 40" < X ≤ 52", 5 52" < X ≤ 72", 6	
1 1/4" Screw (for Base, 1 1/4" Single & 3/4" Double, Inside Mount) (with Rail Cover)	8.5" < X ≤ 40", 6 40" < X ≤ 52", 8 52" < X ≤ 72", 10	
1 1/4" Screw (for Base, 1 1/4" Single & 3/4" Double, Inside Mount) (without Rail Cover)	4	
M3.8x38mm screw (for Outside Mount)	L bracket qty*2	
Spacer Block (Optional, Outside Mount)	1pc to extend distance 3/8" 2pcs to extend distance 1 1/16"	
M3x3.6mm Screw (for 3/8" Single, Outside Mount) (Without Rail Cover)	L bracket qty	
M3x3.6mm Screw (for 3/4" Single, 1/2" Double & 9/16" Single Outside Mount) (Without Rail Cover)	4	
M3x3.6mm Screw (for 3/8" Single, 3/4" Single, 1/2" Double & 9/16" Single Outside Mount) (With Rail Cover)	2	

## Bracket Installation

**Notes: when installing the Cord Equalizer Housing Cover, it is suggested to secure the bottom covers**

first and then unfasten the top cord to secure the top covers.

**A. Without Rail Cover**  
 (Only available for 3/8" Single, 1/2" Double, 9/16" Single, 3/4" Single, not available for 1 1/4" Single & 3/4" Double)



Step1

### ★Inside Mount


For flush mount, the minimum distance from the top/bottom wall to the Cord Equalizer Housing base side is B and A from the side wall to the edge of Base. Use M3.5x25mm Screw to secure the base. Align the cover with the notch of the base and push the cover in toward the wall.

### TOP:

For 3/8" Single, A=7/16" & B=3/8"

For 9/16" Single, A=7/16" & B=1/2"

For 3/4" Single & 1/2" Double, A=7/16" & B=5/8"




### BOTTOM:

For 3/8" Single, A=7/16" & B=3/8"

For 9/16" Single, A=7/16" & B=1/2"


For 3/4" Single & 1/2" Double, A=7/16" & B=5/8"




### ★Outside Mount

**TOP:** Use two M3.8x38mm screws to fasten the L bracket.


Once the L bracket is installed, use one M3 x 3.6mm bolt to attach base. Finally, align the cover with the notch of the base and push the cover in, as shown in "Inside Mount" illustration.



(The shade width and length is 4" larger than the window opening)



**BOTTOM:** Follow the directions provided for the Top L brackets, but reverse the direction.



(The shade width and length is 4" larger than the window opening)

Use M3.8x38mm screws to fasten the L bracket and one M3x 3.6mm bolt to attach base on L bracket.





For 3/4" Single, 1/2" Double & 9/16" Single, when L bracket qty is more than 4pcs, please install the extra L brackets on top to attach with the magnets in the headrail.

Step1: place the L brackets on four corners


Step2: if there's one extra L bracket, measure from left headrail end cap to middle of first magnet to locate the extra L bracket and mark on the wall

Step3: if there're more L brackets, measure from left headrail end cap to middle of second / third magnet to locate the L brackets and mark on the wall.





the cover in toward the wall as below diagram shows.




### ★Outside Mount

**Outside Mount –for 3/8"Single Cell, 1/2"Double Cell, 9/16"Single Cell & 3/4"Single Cell (Not available for larger cell size)**


Use two M3.8x38mm screws to fasten the L bracket. Then, align the cover with the notch of the base and push the cover in, as shown in "Inside Mount" illustration.

TOP



BOTTOM

Use M3.8x38mm screws to fasten the L bracket and one M3x 3.6mm bolt to attach base on L bracket.



**TIP:** Once the hardware is in place, make sure to keep the cords pulled tight. The shade should not sag or feel loose, if it does please pull the cords taut.


### B. With Rail Cover

#### ★Inside Mount

For flush mount, use M3.5x25mm Screw to secure the rail cover and the base.  
For 3/8"Single, 9/16"Single, 3/4"Single & 1/2"Double, A=5/8"  
For 3/4"Double & 1 1/4"Single, A=1 1/4"

TOP:


BOTTOM:




Align the cover with the notch of the base and push

### Handle Installation

Slide the handle onto the handle base that is pre-attached to the rails.




### Operate your shade




### Notes

For child safety, please check and ensure that there are no loose cords after the shade is completely installed. If the shade is too loose, please retie a new knot for it.

Remove bottom Cord Equalizer Housing Covers, untie the knot and make a new knot for adjustment. Please do not tie the cord too tight as it will cause too much friction.




Please also make sure that cords are nice and tight and not tangled.



### Cleaning


Routine cleaning will help maintain the beauty of your shade. The shade can be cleaned by using a soft brush, vacuumed with a low suction hand-held vacuum, cleaned ultrasonically (specify that a mild solution must be used and that the headrail should

never be immersed in liquid). Spot cleaning is not recommended, but if necessary, dampen a clean cloth with a solution of warm water and mild detergent to dab the spot until it's gone (do not rub!).




*Some options listed may not be applicable.*

MOTORIZED CELLULAR SHADE MANUAL



NO.	Item	Specification
1	Power Source	MCS1-A: AC Adapter MCS1-B: Li-ion Battery
2	Input	MCS1-A: 100-240V, 50/60 Hz MCS1-B: 24V, 1.5A Max
3	Output	MCS1-A: 24V, 1.32A Max. MCS1-B: 10.89V, 1.65A Max.
4	Radio type	2.4G RF
5	Motor type	Brush DC motor
6	Charging type	Power Charger PB-01S Power Charger PB-02
7	Charging Time	< 2 hours
8	Charging Temperature	5°C ~ 35°C / 41°F ~ 95°F
9	Operating Temperature	0°C ~ 40°C / 32°F ~ 104°F
10	Relative Humidity	0% ~ 90% (Non-condensing)

FCC ID: Q3V-MCS1  
IC ID: 28542-MCS1  
CAN ICES-003 (B) / NMB-003(B)



READ BEFORE INSTALLATION

**▲WARNING!** Important safety instructions. Follow all instructions since incorrect installation can lead to severe injury. Before installing the device, remove any unnecessary cords or components and disable any equipment not needed for powered operation.


**▲WARNING!** The installation height will vary according to product type or installation situation and may exceed 98.43" (2.5m).

**▲WARNING!** For the shades powered by battery (MCS1-B), please turn on the shade **AFTER** installation. Press and hold the shade button for 3 seconds, and the green light will flash, which means the shade is powered on.

Reserve space before installation :


**For Model# MCS1-A** : Make sure to provide proper accessibility to an electrical outlet.

**▲IMPORTANT!** Wiring and servicing of these products should be referred to qualified personnel.



**For Model# MCS1-B** : with built-in Li-ion battery pack and charging accessories.

**IMPORTANT!** For Model #MCS1-B with built in Li-ion battery pack, please mount the headrail correctly. Make sure the headrail is level and that it doesn't tilt forward. Improper installation may cause the charging wand to not make full contact with the charging port. The shade installation only allows up to 3° of deflection tolerance.



TOOLS YOU WILL NEED

- Level
- Measuring Tape
- Pencil
- Power Drill (6mm hex driver and drill bit)
- Screwdriver




You will need to use the following fasteners for your particular mounting surface.

Surface	Fastener
Wood	Screws (Provided)
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provided)
Metal	Sheet Metal Screws (Not Provided)

GETTING STARTED


Check Standard Components/Hardware:




Hardware Standard Quantity:

Order Width (X)	Less or Equal to 64"	Between 64-1/8" and 112"	Over 112"
Installation Bracket	2	3	4
Installation Bracket Screw	4	6	8
Spacer Block (Optional)	Varies per order request: 1pc / bracket or 2pcs/bracket		
Hold Down Bracket (Optional)	2	2	2
Hold Down Bracket Screw (Optional)	4	4	4

Check Components for MCS1-A for AC Adapter:



Check Components for MCS1-B for Battery:




MOUNTING INSTALLATION BRACKETS

The installation bracket may be used for **INSIDE** or **OUTSIDE** mounts.

**Please always avoid the charging port when placing the brackets. Mounting the brackets level is essential for proper operation of the shade.**


Shim the brackets if necessary to achieve a level alignment. The bracket requirements and placement are the same for inside and outside mount.

Measure 8" from both ends of the headrail. Mark the bracket location on the mounting surface. Proper alignment of brackets will make installation easier.




Inside Mount:

Allow a minimum of 1/16" distance from the front of brackets to the edge of window opening as shown in the drawing on the right. Use two installation screws to secure brackets. Use wall anchors for drywall or plaster wall.




\* For shallow mounting, use 2 flat head screws to secure the bracket as shown in the drawing on the right.




Outside Mount:

Use 2 flat head screws to secure each bracket. Use wall anchors for drywall or plaster wall.




Note: If spacer block is provided, please follow this guide: Please always make sure the raised side of the spacer block is against the bracket.



Install the Shade:

Position the head rail at an angle so that it is hooked to the front of the bracket. Then push it upward at the back to snap into the bracket.




Note: You will hear a click sound once the head rail is properly secured.

Install Hold Down Bracket (Optional):

A. For Hold Down Brackets.


Use screw to secure each bracket.



Inside Mount    Outside Mount


B. For Magnetic Hold Down

Use M3x15mm screw to secure the magnet catch at the below location. Make sure the magnet catch align with the pre-installed magnet on shade bottom rail.



REMOVING THE SHADE

Fully raise the shade, and then gently remove the bracket off the headrail with a flat screwdriver.



Congratulations!

You have finished installing the product.

Please also note that for shades with rechargeable batteries, the batteries will come with enough power to test your shade immediately after installation. Rechargeable batteries will be shipped out with approximately 50% battery to allow for testing. However, it is recommended to charge your battery to full before using your shade for other purposes. To check the battery level, please refer to the power charger manual.

Scan to learn more






MOTORIZED CELLULAR SHADE  
WITH DUAL MOTOR MANUAL

DMCS1-A	
TDBU	Day & Night
36W AC Adapter	
65W AC Adapter	
DMCS1-B	
TDBU	Day & Night

NO.	Item	Specification
1	Power Source	DMCS1-A: AC Adapter DMCS1-B: Li-ion Battery
2	Input	DMCS1-A: 100-240V, 50/60 Hz DMCS1-B: 24V, 1.5A Max
3	Output	DMCS1-A: 24V, 1.1A Max. DMCS1-B: 10.89V, 1.3A Max.
4	Radio type	2.4G RF
5	Motor type	Brush DC motor
6	Charging type	Power Charger PB-01S Power Charger PB-02
7	Charging Time	< 2 hours
8	Charging Temperature	5°C ~ 35°C / 41°F ~ 95°F
9	Operating Temperature	0°C ~ 40°C / 32°F ~ 104°F
10	Relative Humidity	0% ~ 90% (Non-condensing)

FCC ID: Q3V-DMCS1  
IC ID: 28542-DMCS1  
CAN ICES-003 (B) / NMB-003(B)



READ BEFORE INSTALLATION

**▲WARNING!** Important safety instructions. Follow all instructions since incorrect installation can lead to severe injury. Before installing the device, remove any unnecessary cords or components and disable any equipment not needed for powered operation.


**▲WARNING!** The installation height will vary according to product type or installation situation and may exceed 98.43" (2.5m).

**▲WARNING!** For shades powered by battery (DMCS1-B), please turn on the shade **AFTER** installation. Press and hold the shade button for 3 seconds, and the green light will flash, which means the shade is powered on.

Reserve space before installation :


**For Model# DMCS1-A** : Make sure to provide proper accessibility to an electrical outlet.

**▲IMPORTANT!** Wiring and servicing of these products should be referred to qualified personnel.



**For Model# DMCS1-B** : with built-in Li-ion battery pack and charging accessories.

**IMPORTANT!** For Model #DMCS1-B with built in Li-ion battery pack, please mount the headrail correctly. Make sure the headrail is level and that it doesn't tilt forward. Improper installation may cause the charging wand to not make full contact with the charging port. The shade installation only allows up to 3° of deflection tolerance.



TOOLS YOU WILL NEED

- Level
- Measuring Tape
- Pencil
- Power Drill (6mm hex driver and drill bit)
- Screwdriver




You will need to use the following fasteners for your particular mounting surface.

Surface	Fastener
Wood	Screws (Provided)
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provided)
Metal	Sheet Metal Screws (Not Provided)

GETTING STARTED


Check Standard Components/Hardware:




Hardware Standard Quantity:

Order Width (X)	Less or Equal to 64"	Between 64-1/8" and 112"	Over 112"
Installation Bracket	2	3	4
Installation Bracket Screw	4	6	8
Spacer Block (Optional)	Varies per order request: 1pc / bracket or 2pcs/bracket		
Hold Down Bracket (Optional)	2	2	2
Hold Down Bracket Screw (Optional)	4	4	4

Check Components for DMCS1-A for AC Adapter:



Check Components for DMCS1-B for Battery:




MOUNTING INSTALLATION BRACKETS

The installation bracket may be used for **INSIDE** or **OUTSIDE** mounts.

**Please always avoid the charging port when placing the brackets. Mounting the brackets level is essential for proper operation of the shade.**


Shim the brackets if necessary to achieve a level alignment. The bracket requirements and placement are the same for inside and outside mount.

Measure 8" from both ends of the headrail. Mark the bracket location on the mounting surface. Proper alignment of brackets will make installation easier.




Inside Mount:

Allow a minimum of 1/16" distance from the front of brackets to the edge of window opening as shown in the drawing on the right. Use two installation screws to secure brackets. Use wall anchors for drywall or plaster wall.




\* For shallow mounting, use 2 flat head screws to secure the bracket as shown in the drawing on the right.




Outside Mount:

Use 2 flat head screws to secure each bracket. Use wall anchors for drywall or plaster wall.




Note: If spacer block is provided, please follow this guide:  
Please always make sure the raised side of the spacer block is against the bracket.



Install the Shade:

Position the head rail at an angle so that it is hooked to the front of the bracket. Then push it upward at the back to snap into the bracket.




Note: You will hear a click sound once the head rail is properly secured.

Install Hold Down Bracket (Optional):

A. For Hold Down Brackets.


Use screw to secure each bracket.



Inside Mount      Outside Mount


B. For Magnetic Hold Down

Use M3x15mm screw to secure the magnet catch at the below location. Make sure the magnet catch align with the pre-installed magnet on shade bottom rail.



REMOVING THE SHADE

Fully raise the shade, and then gently remove the bracket off the headrail with a flat screwdriver.



Congratulations!  
You have finished installing the product.

Please also note that for shades with rechargeable batteries, the batteries will come with enough power to test your shade immediately after installation. Rechargeable batteries will be shipped out with approximately 50% battery to allow for testing. However, it is recommended to charge your battery to full before using your shade for other purposes. To check the battery level, please refer to the power charger manual.


Scan to learn more





N301466  
65101-11539

Installation & Maintenance Instructions



Cordless Cellular 3/4" S OPP Collection

Getting Started




NOTE: Prior to installation, please make sure your hands are clean and free from any dirt or oil that could cause damage to the fabric.

Recommended Tools

- Measuring Tape
- Pencil
- Level
- Screwdriver
- Power Drill (1/4" hex driver and drill bit)



You will need to use the following fasteners for your particular mounting surface.

Surface	Fastener
Wood	#8 1 1/4" Screws (Provided) 
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provided) 
Metal	Sheet Metal Screws (Not Provided) 

Check Component / Hardware



Installation Bracket



Handle




Hold Down Bracket & #6 3/4" screws (optional)

Hardware Standard Quantity

Order Width (X)	Less or Equal to 39"	Between 39" ~ 66"	Over 66"
Installation Bracket	2	3	4
1 1/4" Screw for Installation Bracket	4	6	8
Handle	Width less or equal to 72"(1829mm):1pcs Width over 72": 2pcs		

Step 1: Bracket Installation


Measure 5" from both ends of the headrail. Mark the bracket location on the mounting surface.



Inside Mount

For the shade to operate properly when inside mounted: Check to make sure there is enough depth clearance for the installation bracket and no obstructions.

If you would like your shade to be flush with the wall, leave a distance of 1/4" from the wall to the front of the bracket.




Outside Mount

Hold the bracket against the wall. Mark a line at every bracket location (shown on the picture).


Make sure the lines are level with each other.

The min. distance from the wall to the bottom of the bracket needs to be 1/4".




Step 2. Shade Installation


Position the head rail at an angle so that it hooks into the front of the bracket. Then push upward to snap the head rail into the bracket.



Step 3. How to Install Shade Handle

Hook the top part of the handle onto the rail rib. Push the handle downward so it clips to the bottom of the rail. You will hear a loud click sound once the handle is properly secured






#### Step 4. Shade Operation

**To lower the shade**, gently pull down the shade by the bottom rail handle and stop at the desired location.

**To raise the shade**, gently raise the shade by the bottom rail handle to the desired height.




#### Step 5. How to Install Hold Down (optional for outside mount)

Use #6 3/4" screw to secure each bracket.




#### How to Uninstall Shade Handle

Use a flat head screwdriver to remove the handle from the bottom of the rail.  
(To avoid scratching the rail with the screwdriver: Please put a piece of adhesive tape on the head of the screwdriver before removing the handle from the rail.)



#### Shade Removal

Fully raise the shade that you want to remove.  
Gently pry the bracket off the head rail with a flat screwdriver as shown in the below picture.  
Remove the shade.



#### Clean the Shade

Routine cleaning will help maintain the beauty of your shade. The shade can be cleaned by using a soft brush, vacuumed with a low suction hand-held vacuum, cleaned ultrasonically (a mild solution must be used and the head rail should never be immersed in liquid). Spot cleaning is not recommended, but if necessary, dampen a clean cloth with a solution of warm water and mild detergent to dab the spot until it's gone (do not rub!).

★ **Congratulations! You have finished installing the shade.**