


N300473-10
65101-11725-J

Installation Instructions

Honeycomb Shades

Corded / Corded TDBU / Corded Day & Night



Getting Started

Remove the shade from the package. Save the packaging until the shade is installed and working to your satisfaction.

Tools Needed :

- Power drill and drill bit
- Measuring tape
- Screwdriver
- Level
- Pencil
-



You will need to use the following fasteners for your particular mounting surface.

Surface	Fastener
Wood	1 1/4" Screws (Provide) for 3/8"S
	for 3/8"D & 3/4"S
	3/4" Screws (Provide)
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provide)
Metal	Sheet Metal Screws (Not Provide)

Check Component/Hardware:



Installation Bracket



Cord Cleat



Hold Down bracket (optional)

Hardware Standard Quantity

Order Width (X)	8 1/2" ≤ X ≤ 42"	42" < X ≤ 75"	X > 75"
Installation Bracket	2	3	4
1 1/4" Screw for 3/8"S Installation Bracket	2	3	4
1 1/4" Screw for 3/4"S, 1/2"D & 9/16"S Installation Bracket	4	6	8
Cord Cleat	1pc for Corded, 2pcs for Corded TDBU & Day & Night		
3/4" Screw for Hold Down Bracket/ Cord Cleat	Hold Down Bracket qty*2 + Cord Cleat qty		
2" Screw for Installation Bracket with spacer	4	6	8
Hold Down Bracket (Optional)	2	2	2
Spacer (Optional)	2	3	4


Note: You may find more hardware parts than you actually need. In that case, feel free to set them aside for future use.

* Cord cleat is included.

* Optional hardware parts, such as spacers and hold down brackets, are available upon request.

Step 1: Bracket Installation

Measure 3" from both ends of the head rail. Mark the bracket location on the mounting surface. Proper alignment of brackets will make installation easier.




a. for 1/2" Double cell, 9/16" Single cell & 3/4" Single cell

Allocate a min. distance of 3/16" from wall to the front of brackets. Use two 1 1/4" mounting screws to secure brackets. Use wall anchors for drywall or plaster wall. (Align the front of brackets flush with wall if only lock the back hole in the brackets.)

Outside Mount:


Allocate a min. distance of 5/16" from the end of brackets to the top window frame. Use two 1 1/4"



mounting screws to secure brackets. Use wall anchors for drywall or plaster wall.


b. for 3/8" Single cell Inside Mount:

Allocate a min. distance of 5/16" from the edge of the wall to the front of brackets. Use two 1 1/4" mounting screws to secure brackets.




Outside Mount:

Allocate a minimum distance of 3/16" from the end of brackets to the top window frame. Use two 1 1/4" mounting screws to attach each bracket.




* For shallow mounting, using flat head screw to secure the bracket in 45°.



Step 2: Shade Installation

- Position the shade so that the front is facing you.
- Insert the rail with an angle facing the window; hooking up with the bracket front side, and then push it upward to snap into the bracket. For proper installation, start with attaching the front rail to the bracket.


⚠ For easier installation, move the middle rail of corded TDBU a little bit off before installing the headrail.



Step 3: How to Install Hold Down Brackets (optional)


A, For Hold Down Bracket.

Use two 3/4" screws to secure each hold down bracket.



B. For Magnetic Hold Down

Use M3x15mm screw to secure the magnet catch at the below location. Make sure the magnet catch align with the pre-installed magnet on shade bottom rail.




Step 4: Shade Operation

For Corded TDBU & Day & Night: when lowering the shade, pull the left cord to lower the bottom rail first and then pull the right cord to lower the middle rail. When raising the shade, reverse operation. Raise the middle rail first and then bottom rail.

Step 5: Cord Cleat

Install the cord cleat on the wall. Wrap the operating cords around the cord cleat for child safety. Always use the cord cleat to keep cords out of the reach of children. The cleat should be installed more than 64" (1.6m) from the door.




Remove the Shade

- For Corded, Fully raise the shade
- For Corded TDBU & Day & Night, Lower the mid rail
- Insert screwdriver into the gap between the back of the rail and the bracket. Gently maneuver the screwdriver toward yourself to pry the bracket.



How to Reassemble Ellipse Safety Cord Connector



Our Shade comes equipped with an Ellipse Safety Cord Connector that prevents child strangulation. If the device comes apart, please refer to below steps:


1. Open the Ellipse Safety Cord Connector entirely.
2. Align all cords and slide them into the slot of Ellipse Safety Cord Connector;
3. Close the Ellipse Safety Cord Connector;
4. Pull the tassel cords and make sure it is closed tightly

Cleaning

Routine cleaning will help maintain the beauty of your shade. The shade can be cleaned by using a soft brush, vacuumed with a low suction hand-held vacuum, cleaned ultrasonically (specify that a mild solution must be used and that the head rail should never be immersed in liquid), or dampen a clean cloth with a warm water and mild detergent solution to dab the spot until it's gone (do not rub!).


Troubleshooting

Problem	Solution
For corded TDBU & Day & Night, if the bottom shade fabric not remain stacked (billowed on the windowsill), when the top was lowered	When lower the bottom shade, please pull the left side cord leftwards to lock the bottom rail. Please make sure the bottom rail is locked right above the windowsill first (if not locked, please try more times) before operating the top shade.



Window Blind Cord Can STRANGLE Your Child

- Children can strangle in the loop above the cord bead.
- Children can climb furniture to reach cords.
- Move crib and furniture away.
- Shorten cords to prevent reach.
- Keep cords separate. Twisted or knotted cords can create a loop.
- Keep all cords out of children's reach.




La cuerda de la persiana puede ESTRANGULAR su niño

- Los niños se pueden estrangular en el lazo por encima del cordón.
- Los niños pueden subir los muebles para alcanzar las cuerdas.
- Mueva la cuna y los muebles.
- Acorte las cuerdas para evitar el alcance.
- Mantenga las cuerdas separadas. Los cordones retorcidos o anudados pueden crear un lazo.
- Mantenga todas las cuerdas fuera del alcance de los niños.

N300750
65101-10249

Installation Instructions Honeycomb Shades

Cordless & Cordless TDBU & Cordless Day & Night



Getting Started

Remove shade from package. Save packaging until shade is installed and working to your satisfaction.

Tools:



- Level
- Measuring Tape
- Pencil
- Power drill
- (1/4" hex driver and drill bit)
- Screwdriver



You will need to use the following fasteners for your particular mounting surface.

Surface	Fastener
Wood	#8 1 1/4" Screws (Provide) #6 3/4" screws
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provide)
Metal	Sheet Metal Screws (Not Provide)

Check Component/Hardware:



Handle



Hold Down bracket (optional)


Hardware Standard Quantity

Order Width (X)	X ≤ 39"	39" < X ≤ 66"	66" < X ≤ 93"	93" < X ≤ 120"
Installation Bracket	2	3	4	5
Handle	1pcs for X ≤ 50", 2pcs for X > 50" (Cordless) 2pcs for X ≤ 50", 4pcs for X > 50" (Cordless TDBU & Day & Night)			
1 1/4" Screw for Installation Bracket	4	6	8	10
Hold Down Bracket (Optional)	2	2	2	2
Spacer (Optional)	1pc for extend distance 10mm 2pcs for extend distance 18mm			
2" Screw for Installation Bracket with spacer (Optional)	4	6	8	10
3/4" Screw for Hold Down Bracket (Optional)	4	4	4	4

Note: Optional flat head screws included.
Use as needed.


Step 1: Bracket Installation

- Measure 3" from both ends of the head rail. Mark the bracket location on the mounting surface




Inside Mount

- For Cordless, align wall to the front of brackets.
- For Cordless TDBU & Day & Night, allocate a min. distance of 1 1/16" from wall to the front of brackets.
- Use two 1 1/4" mounting screws to secure brackets. Use wall anchors for drywall or plaster wall.



Outside Mount

- Align the end of brackets with the top window frame.
- Use two #8 1 1/4" mounting screws to secure brackets. Use wall anchors for drywall or plaster wall.




Step 2: Shade Installation

- Position head rail at an angle so that it is hooked to the front of the bracket. Then push it upward to snap into the bracket.


⚠ For proper installation, start with attaching the front rail to the bracket.

⚠ For easier installation, move the middle rail of cordless TDBU a little bit off before installing the headrail.




Step 3: How to Install Shade Handle

Position the handle at angle so that it is hooked to the bottom of the bottom rail. Then push it upward to snap into place.



Shade Operation



To lower the shade, gently pull down the shade on the bottom rail handle and stop at the desired location.

For TDBU & Day & Night, pull down the bottom rail first before lowering the middle rail.

To raise the shade, gently raise the shade on the bottom rail handle to desired height.


For TDBU & Day & Night, if the shade will not lift, pull the midrail down fully to the bottom first and then raise up bottom rail together with midrail.

⚠ Do not grasp the rail unevenly. Always lower or raise the shade in the middle or use both hands with even pressure to two handles of the rail.

How to Install Hold Down (If applicable)


A, For Hold Down Bracket.

Use #6 3/4" screw to secure each bracket.




B. For Magnetic Hold Down

Use M3x15mm screw to secure the magnet catch at the below location. Make sure the magnet catch align with the pre-installed magnet on shade bottom rail.



Remove the Shade

For cordless, fully raise the shade.
For TDBU & Day & Night, Lower the middle rail.
Gently pry the bracket off the head rail with a flat screwdriver as below picture.
Remove the shade.




Cleaning the Shade

Routine cleaning will help maintain the beauty of your shade. The shade can be cleaned by using a soft brush, vacuumed with a low suction hand-held vacuum, cleaned ultrasonically (specify that a mild solution must be used and that the head rail should never be immersed in liquid), or dampen a clean cloth with a warm water and mild detergent solution to dab the spot until it's gone (do not rub!).


Troubleshooting

Problem	Solution
The shade will not snap into the mounting brackets	Check if mounting brackets are aligned. Refer to Step 1.
The shade will not lift	Gently pull down on the bottom rail to reactivate the cordless mechanism. Repeat if necessary. For TDBU & Day&Night, pull the midrail down fully to the bottom first and then raise the bottom rail together with midrail up.
The shade stack up unevenly	Lower the shade completely, then raise it up to correct it. Repeat if necessary.



N300616-4
65101-11753-D

Installation Instructions
Honeycomb Shades
Cordless & Cordless TDBU & Cordless Day&Night
(3/4" Double & 1 1/4" Single)



Getting Started

Remove shade from package. Save packaging until shade is installed and working to your satisfaction.

Tools:

- Level
- Measuring Tape
- Pencil
- Power drill (1/4" hex driver and drill bit)
- Screwdriver




You will need to use the following fasteners for your particular mounting surface.

Surface	Fastener
Wood	#8 1 1/4" Screws (Provide) #6 3/4"screws
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provide)
Metal	Sheet Metal Screws (Not Provide)

Check Component/Hardware:



Hold Down bracket (Optional)



Installation Bracket

Hardware Standard Quantity


Order Width (X)	X ≤ 39"	39" < X ≤ 66"	66" < X ≤ 93"	93" < X ≤ 96"
Installation Bracket	2	3	4	5
Handle	1pcs for X ≤ 50", 2pcs for X > 50" (Cordless) 2pcs for X ≤ 50", 4pcs for X > 50" (Cordless TDBU & Day & Night)			

1 1/4" Screw for Installation Bracket	4	6	8	10
Hold Down Bracket (Optional)	2	2	2	2
Spacer (Optional)	1pc for extend distance 10mm 2pcs for extend distance 18mm			
3/4" Screw for Hold Down Bracket (Optional)	4	4	4	4
2" Screw for Installation Bracket with spacer (Optional)	4	6	8	10

Note: Optional flat head screws included.
Use as needed.



Step 1: Bracket Installation

- Measure 3" from both ends of the head rail. Mark the bracket location on the mounting surface





Inside Mount

- Allocates a min. distance of 1/8" from wall to the front of brackets.
- Use two #8 1 1/4" mounting screws to secure brackets. Use wall anchors for drywall or plaster wall.




Outside Mount

- Align the end of brackets with the top window frame.
- Use two #8 1 1/4" mounting screws to secure brackets. Use wall anchors for drywall or plaster wall.



* For shallow mounting, using flat head screw to secure the bracket in 45°.




Step 2: Shade Installation

Position head rail at an angle so that it is hooked to the front of the bracket. Then push it upward to snap into the bracket.


- ⚠ For proper installation, start with attaching the front rail to the bracket.

- ⚠ For easier installation, move the middle rail of cordless TDBU a little bit off before installing the headrail.




Step 3: How to Install Shade Handle

Position the handle at an angle so that it is hooked to the bottom of the bottom rail. Then push it upward to snap into place.



Congratulations! You have finished installing the blind.

Shade Operation



To lower the shade, gently pull down the shade on the bottom rail handle and stop at the desired location.
For TDBU & Day & Night, pull down the bottom rail first before lowering the midle rail.

To raise the shade, gently raise the shade on the bottom rail handle to desired height.


For TDBU & Day & Night, if the shade will not lift, pull the midrail down fully to the bottom first and then raise the bottom rail together with midrail up.

- ⚠ Do not grasp the rail unevenly. Always lower or raise the shade in the middle or use both hands with even

pressure to two handles of the rail.


How to Install Hold Down Brackets (optional)

A, For Hold Down Bracket.




Use #6 3/4" screw to secure each bracket.

Use #6 3/4" screw to secure the magnet catch at the below location. Make sure the magnet catch align with the pre-installed magnet on shade bottom rail.



Remove the Shade

For corded, fully raise the shade.
For TDBU and Day & Night, Lower the middle rail. Gently pry the bracket off the head rail with a flat screwdriver as below picture. And then remove the shade.




Cleaning the Shade

Routine cleaning will help maintain the beauty of your shade. The shade can be cleaned by using a soft brush, vacuumed with a low suction hand-held vacuum, cleaned ultrasonically (specify that a mild solution must be used and that the head rail should never be immersed in liquid), or dampen a clean cloth with a warm water and mild detergent solution to dab the spot until it's gone (do not rub!).

Troubleshooting

Problem	Solution
The shade will not snap into mounting brackets	Check if mounting brackets are aligned. Refer to Step 1.
The shade will not lift	Gently pull down on the bottom rail to reactivate the cordless mechanism. Repeat if necessary. For TDBU & Day&Night, pull the midrail down fully to the bottom first and then raise the bottom rail together with midrail up.
The shade stack up unevenly	Lower the shade completely, then raise it up to correct it. Repeat if necessary.



Installation Instructions

Honeycomb Shades

Cord Loop



Getting Started

Remove shade from package. Save packaging until shade is installed and working to your satisfaction.

Tools:


- Power drill
- Tape measure
- Screwdriver
- Level
- Pencil



Installation Screws

Surface	Fastener
Wood	#8 1 1/4" Screws (Provided)
	M4x48mm screws
	#6 3/4" screws
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provide)
Metal	Sheet Metal Screws (Not Provide)

Check Component/Hardware:



Hold Down Brackets (Optional)


Hardware Standard Quantity

Order Width (X)	X ≤ 39"	39" < X ≤ 66"	66" < X ≤ 93"	93" < X ≤ 120"
Installation Bracket	2	3	4	5
M4x48mm Screw for Tensioner	2	2	2	2
1 1/4" Screw for Installation Bracket	4	6	8	10
3/4" Screw for Hold Down Bracket(Optional)	4	4	4	4
2" Screw for Installation Bracket with spacer block(Optional)	4	6	8	10
Hold Down Bracket (Optional)	2	2	2	2
Spacer Block(Optional)	1pc for extend distance 10mm 2pcs for extend distance 18mm			

Note: Optional flat head screw included. Use as needed.


Step 1: Bracket Installation

Measure 3" from both ends of the head rail. Mark bracket location on the mounting surface.




Inside Mount


• Use two #8 1 1/4" mounting screws to secure brackets. Use wall anchors for drywall or plaster wall.



• For 3/8"S, 1/2"D, 9/16"S, 3/4"S, allocate a min. distance of 1/16" from wall to the front of brackets as left drawing.




Outside Mount



• For 1 1/4"S, 3/4"D, align the front of brackets to the edge of window opening as right drawing.


• For 3/8"S, 1/2"D, 9/16"S, 3/4"S, allocate a min. distance of 5/8" from wall to the bottom of brackets as left drawing.



• For 1 1/4"S, 3/4"D, align the end of brackets with the top window frame as left drawing.

• Use two #8 1 1/4" mounting screws to attach each bracket. Use wall anchors for drywall or plaster wall.



*** For shallow mounting, using flat head screw to secure the bracket in 45° .**



Step 2: Shade Installation


• Position head rail at an angle so that it is hooked to the front of the bracket. Then push it upward to snap into the bracket.

⚠ For proper installation, start with attaching the front rail to the bracket.



Step 3: Cord Tensioner Installation

- Make sure the cord is tightened / taut without stretching, twisting or crossing, and the tensioner and control cord does not interfere with raising or lowering the shade before cord tensioner is mounted.
- Use 2pcs M4x48mm screws to mount the cord tensioner to the wall or window frame firmly for both inside & outside mount. Please refer to the following steps:




★ Congratulations! You have finished installing the blind.

How to Install Hold Down Brackets (optional)


A, For Hold Down Bracket.

• Use #6 3/4" screw to secure each bracket.



B. For Magnetic Hold Down

Use M3x15mm screw to secure the magnet catch at the below location. Make sure the magnet catch align with the pre-installed magnet on shade bottom rail.




Note

- Keep away from heat, sparks and open flame.
- Larger windows may require two people to install.
- Proper In the process of installation, must support the shade firmly to avoid it fall down too quick to damage the people or itself.
- Operate shade only by pulling the cord.
- To ensure child safety, install cord cleat and tighten up any loose cords after the shade is installed



Shade Operation

● **For Cordloop**, Pull cord to operate shade. Cord Tensioner must be fully tightened prior to operating the shade.




Remove the Shade

- Fully raise the shade.
- Gently pry the bracket off the head rail with a flat screwdriver.
- Remove the shade.



Cleaning

Routine cleaning will help maintain the beauty of your shade. The shade can be cleaned by using a soft brush, vacuumed with a low suction hand-held vacuum, cleaned ultrasonically (specify that a mild solution must be used and that the head rail should never be immersed in liquid), or dampen a clean cloth with a warm water and mild detergent solution to dab the spot until it's gone (do not rub!)



Installation Instructions

Honeycomb Shades Motorized Cordless



Getting Started

Remove shade from package. Save packaging until shade is installed and working to your satisfaction.

Tools:



- Level
- Measuring Tape
- Pencil
- Power drill (6mm hex driver and drill bit)
- Screwdriver





You will need to use the following fasteners for your particular mounting surface.

Surface	Fastener
Wood	Screws (Provide)
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provide)
Metal	Sheet Metal Screws (Not Provide)

Check Component/Hardware:



(3/8"S, 1/2"D, 9/16"S, 3/4"S) (1 1/4"S, 3/4"D)
Installation Bracket 1 1/4" Installation Screw



Spacer (Optional) 2" Screw (Optional) 2.5" Screw (Optional) 9/16" Screw (Optional)


Hardware Standard Quantity

Order Width (X)	$X \leq 56"$	$56" < X \leq 105"$	$X > 105"$
Installation Bracket	2	3	4
1 1/4" Screw (for Installation Bracket)	4	6	8
Spacer Block (Optional)	2	3	4
2" Screw (for Installation Bracket with 1~2pcs spacer block)	4	6	8
2.5" screw (for Installation Bracket with 4pcs spacer block)	4	6	8

Note: Optional flat head screws included. Use as needed.


Step 1: Bracket Installation

- Measure 1 9/16" (40mm) from both ends of the head rail. Mark the bracket location on the mounting surface. Proper alignment of brackets will make installation easier.
- When shade width is less than 24", the distance from both ends of the headrail is 1 3/16" (30mm).




Inside Mount

• For 3/8"S, 1/2"D, 9/16"S, 3/4"S, align the front of brackets 1/16" to the edge of window opening as right drawing.




• For 1 1/4"S, 3/4"D, align the front of brackets to the edge of window opening as right drawing.




Use two 1 1/4" installation screws to secure brackets. Use wall anchors for drywall or plaster wall.

Outside Mount



• For 3/8"S, 1/2"D, 9/16"S, 3/4"S, allocate a min. distance of 5/8" from wall to the bottom of brackets as left drawing.




• For 1 1/4"S, 3/4"D, align the end of brackets with the top window frame as left drawing.

• Use two 1 1/4" installation screws to secure brackets. Use wall anchors for drywall or plaster wall.


Note: If spacer block is required, please follow the following guide:

Please always make sure the raised side of the spacer block is against the bracket.

Use 2" screws for one or two pcs of spacers, and 2.5" screws for 4 pcs of spacers. See picture below:




* For shallow mounting, using flat head screw to secure the bracket in 45°.




Step 2: Install the Shade

- Position head rail at an angle so that it is hooked to the front of the bracket. Then push it upward at the back to snap into the bracket.

⚠ For proper installation, start with attaching the front of the headrail to the bracket.



(3/8"S, 1/2"D, 9/16"S, 3/4"S)




(1 1/4"S, 3/4"D)

Step 4: Install Remote Control Holder (Optional)

Position the remote control holder with two 9/16" screws and the distance between screws is 3 1/4" and screws protrude 1/8".

Attach the remote control holder to the screw.




★ **Congratulations! You have finished installing the blind.**

How to Install Hold Down Brackets (optional)


A. For Hold Down Bracket.

- Use #6 3/4" screw to secure each bracket.




B. For Magnetic Hold Down

Use M3x15mm screw to secure the magnet catch at the below location. Make sure the magnet catch align with the pre-installed magnet on shade bottom rail.



★ Shade Operation

Connect the battery wand or AC/DC adapter to the motor.




Install remote battery and make sure the screen shows the right channel for the shade, and then the shade can be operable. Please refer to the remote instructions for adjustment.

Note: Channel 1 is the default shown on the remote screen and channel 0 controls all shades programmed in one remote.

★ Remove the Shade


Fully raise the shade, and then gently pry the bracket off the head rail with a flat screwdriver. Remove the shade.



★ Manual Control Button

When remote is not available, the shade can be operated by the manual control button.

⚠ Do not press the manual control button over 4secs.



★ Note

Our remotes are pre-programmed and ready to use.

★ Cleaning the Shade

Routine cleaning will help maintain the beauty of your shade. The shade can be cleaned by using a soft brush, vacuumed with a low suction hand-held vacuum, cleaned ultrasonically (specify that a mild solution must be used and that the head rail should never be immersed in liquid), or dampen a clean cloth with a warm water and mild detergent solution to dab the spot until it's gone (do not rub!).


⚠ Do not spray the liquid to the electric parts of the motorized shade.

N300756
65101-10250

Installation Instructions

Honeycomb Shades

ClearFit™



With Rail Cover

Without Rail Cover

Getting Started

Remove the shade from the package. Save the packaging until the shade is installed and working to your satisfaction.

Tools Needed:

- Power drill and drill bit
- Measuring tape
- Screwdriver
- Level
- Pencil



You will need to use the following fasteners for your particular mounting surface.

Surface	Fastener
Wood	M3.5x25mm Screws (Provided) M3.8x38mm
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provided)
Metal	Sheet Metal Screws (Not Provided)

Hardware

Order Width (X)	$X \leq 50"$	$X > 50"$
Handle	2	4
Cord Equalizer Housing Base(with Rail Cover)	2	
Cord Equalizer Housing Base(without Rail Cover)	4	
L Bracket (for 3/8"S, Outside Mount) (with Rail Cover)	2	N/A
L Bracket (for 3/8"S, Outside Mount) (without Rail Cover)	4	N/A
L Bracket for windows with marble sill (Optional)	2	

L bracket (for 3/4"S, 1/2"D, & 9/16"S Outside Mount) (without Rail Cover)	2
L bracket (for 3/4"S, 1/2"D & 9/16"S, Outside Mount) (without Rail Cover)	4
M3.5x25mm Screw (for Base, 3/8" S, Inside Mount)	$8.5" < X \leq 40"$, 4 $40" < X \leq 50"$, 5
M3.5x25mm Screw (for Base, 3/4"S, 1/2"D, & 9/16"S Inside Mount)	$8.5" < X \leq 40"$, 4 $40" < X \leq 52"$, 5 $52" < X \leq 72"$, 6
M3.8x38mm screw (for Outside Mount)	L bracket qty*2
Spacer Block (Optional, Outside Mount)	1pc to extend distance 10mm 2pcs to extend distance 18mm
M3x3.6mm Screw (for Outside Mount)	L bracket qty

Bracket Installation

A. Without Rail Cover

*Inside Mount



For flush mount, the minimum distance from the top/bottom wall to the Cord Equalizer Housing base side is B and A from the side wall to the edge of Base. Use M3.5x25mm Screw to secure the base. Align the cover with the notch of the base and push the cover in toward the wall.

TOP:

For 3/8"S, A=1/8" & B=3/8"

For 9/16"S, A=1/8" & B=1/2"

For 3/4"S & 1/2"D, A=1/8" & B=5/8"




BOTTOM:

For 3/8"S,
A=1/8" & B=3/8"

For 9/16"S,
A=1/8" & B=1/2"


For 3/4"S&1/2"D,
A=1/8" & B=5/8"




*Outside Mount

TOP: Use two M3.8x38mm screws to fasten the L bracket.


Once the L bracket is installed, use one M3 x 3.6mm bolt to attach base. Finally, align the cover with the notch of the base and push the cover in, as shown in "Inside Mount" illustration.



(The shade width and length is 4" larger than the window opening)




BOTTOM: Install the bracket similar to top steps but in reverse way.



(The shade width and length is 4" larger than the window opening)

Use M3.8x38mm screws to fasten the L bracket and one M3x 3.6mm bolt to attach base on L bracket.




B. With Rail Cover

*Inside Mount


Inside Mount – for 3/8" Single Cell

For flush mount, use M3.5x25mm Screw to secure the rail cover and the base.




Align the cover with the notch of the base and push the cover in toward the wall.

step1




step 2



Inside Mount – for 1/2" Double Cell, 9/16" Single Cell, 3/4" Single Cell

For flush mount, use M3.5x25mm Screw to secure the rail cover.

Align the cover with the notch of the base and push the cover in toward the wall as above picture.




★Outside Mount

Outside Mount –for 3/8”Single Cell, 1/2”Double Cell , 9/16”Single Cell & 3/4”Single Cell


Use two M3.8x38mm screws to fasten the L bracket. Then, align the cover with the notch of the base and push the cover in, as shown in “Inside Mount” illustration.

TOP




BOTTOM

Use M3.8x38mm screws to fasten the L bracket and one M3x 3.6mm bolt to attach base on L bracket.



Side mount L bracket for windows with marble sill (optional)


Allocate a distance of B (B=5/8” for 3/8”S) from bottom corner window frame and use two M3.8x38mm screws to secure the L bracket. Use one M3 x 3.6mm bolt to attach base to the L bracket (through inner screw hole)




Top View

Handle Installation

Slide the handle onto the plastic piece pre-attached to the rails.




Operate you shade



Notes


For child safety, please check and ensure that there are no loose cords after the shade is completely installed.

Please also make sure that cords are nice and tight and not tangled.



Cleaning


Routine cleaning will help maintain the beauty of your shade. The shade can be cleaned by using a soft brush, vacuumed with a low suction hand-held vacuum, cleaned ultrasonically (specify that a mild solution must be used and that the head rail should never be immersed in liquid), or dampen a clean cloth with a warm water and mild detergent solution to dab the spot until it's gone (do not rub!).



N300758
65101-10251

Installation Instructions

Honeycomb Shades ClearFit™ for Skylight



Getting Started




Remove the shade from the package. Save the packaging until the shade is installed and working to your satisfaction.

Tools Needed :

- Power drill and drill bit
- Measuring tape
- Screwdriver
- Level
- Pencil
- Steel wire regulator (Provided)



You will need to use the following fasteners for your particular mounting surface.


Surface	Fastener
Wood	M3.5x25mm Screws (Provided) 
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provided) 
Metal	Sheet Metal Screws (Not Provided) 

Hardware Standard Quantity


Order width (X)	X < 31 3/4"	31 3/4" ≤ X < 45 9/16"	45 9/16" ≤ X ≤ 59"
H/R Bracket	2	3	4
B/R Bracket	3	3	4
L-Shape Supporting Bracket Set (OB only)	3	3	4
Handle	1		
M3 x 3.6mm Screw for L-Shape Supporting Bracket Set	3	3	4
Regulator	1		
M3.5x25mm Screw (For OB)	8	9	12
M3.5x25mm Screw (For IB)	5	6	8

Bracket Installation

Top Rail: Install bracket on each end of the top rail. When there are more than two brackets, the distance between brackets should be equal.




Bottom Rail: Two brackets on each end. If there are five brackets, the fifth bracket should be positioned in the middle of the rail.



Inside Mount


The distance between top rail bracket screw hole to the front of the frame should be at least 9/16", and 2" from the wall. As for bottom rail, min. of 1/2" from bracket screw hole to the front of the frame and 1" from the wall. Mount brackets with M3.5x25mm screws. Aligned horizontally. Use wall anchors for drywall or plaster wall.


 **Do not over tighten the screw.**



Outside Mount

Min. distance between top rail bracket screw hole to the top edge of the frame is 5/8", and 3" to the shade edge. Mount brackets with M3.5x25mm screws. Aligned horizontally.


 **Do not over tighten the screw.**



The distance between bottom rail L bracket screw hole to the bottom edge of the frame should be at least 1 1/8" and 1" from the shade edge.


Mount L brackets with 2 M3.5x25mm screw. Cover the brackets and secure with M3x3.6 screw.


 **Do not over tighten the screw.**



Install the Shade


- Position the shade so that the front is facing you.
- Insert the rail with an angle facing the window; hook from the bracket front and push upward to snap it in.

 For proper installation, start with attaching the front rail to the bracket



Remove the Shade

Fully raise the shade. Insert screwdriver into the gap between the back of the rail and the bracket. Gently maneuver the screwdriver toward yourself to pry the bracket.



Handle Installation


Slide the handle onto the plastic piece that is pre-attached to the rails.






Adjust the Steel Wire

After the installation, tighten the steel wire by sliding the regulator towards the direction as shown on label in Drawing 1.

For easier tightening the steel wire, it is suggested to use a pliers to pull the steel wire towards the bottom rail, and then adjust the regulator pin to tighten the steel wire.


 **Put a cloth between the pliers and steel wire in case the steel wire breaks.**






Cleaning

Routine cleaning will help maintain the beauty of your shade. The shade can be cleaned by using a soft brush, vacuumed with a low suction hand-held vacuum, cleaned ultrasonically (specify that a mild solution must be used and that the head rail should never be immersed in liquid), or dampen a clean cloth with a warm water and mild detergent solution to dab the spot until it's gone (do not rub!).




To loosen the steel wire, place the regulator pin on the bottom rail and press down-as shown in Drawing 2.



Drawing 2

N300478-2
65101-11730-B

Installation Instructions
Honeycomb Shades
Patio Door Vertical & Vertical Day&Night






Getting Started


Remove the shade from the package. Save the packaging until the shade is installed and working to your satisfaction.

Tools Needed :

- Power drill and drill bit
- Measuring tape
- Screwdriver
- Level
- Pencil
- **Pliers**

You will need to use the following fasteners for your particular mounting surface.


Surface	Fastener
Wood	1 1/4" Screws (Provide) 
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provide) 
Metal	Sheet Metal Screws (Not Provide) 



Hardware Standard Quantity

Order Width (X)	X ≤ 39"	39" < X ≤ 66"	66" < X ≤ 93"	93" < X ≤ 120"	X > 120"
Installation Bracket	2	3	4	5	6
Floor Bracket	Right stack 1 Left stack 1 Travelling Center Stack 0 Split Stack(Center Opening) 2 Vertical Day & Night 2				
1 1/4" Screw for Bracket	installation bracket qty x 2 + floor bracket qty				
Spacer Block (Optional)	1pcs for extend distance 10mm 2pcs for extend distance 18mm				
Extension Bracket	2	3	4	5	6
Bolt	Right stack 1 Left stack 1 Travelling Center Stack 2 Split Stack(Center Opening) 2 Vertical Day & Night 2				
Hanger	Same as clip qty				


Note: Optional flat head screws included. Use as needed.



Measure 3"~4" from both ends of the head rail. Mark the bracket location on the mounting surface, proper alignment of brackets will make installation easier.

Inside Mount:

Align the front of brackets flush against the wall. Use two 1 1/4" mounting screws to secure brackets. Use wall anchors for drywall or plaster wall.




Outside Mount:

Position the top of bracket at order height +1/8". Use two 1 1/4" mounting screws to secure brackets. Use wall anchors for drywall or plaster wall.

Step 2: Shade Installation

a. Assemble the clips(pre-attached on the blanket) into hangers(find in hardware box) by using pliers as below photo. For convenient operation, reverse the shade when open the package and face to the back of blanket.


b. Position head rail at an angle so that it is hooked to the front of the bracket. Then push it upward to snap into the bracket as shown below.



c. Install unmovable vertical rail


Push the unmovable vertical rail from down to up as below drawing ②. And then, push the fixing hanger into the gap of headrail as drawing ③. Locking the fixing hanger bolt tightly.

Note: Before installing the unmovable vertical rail, **don't's untie cords**. Attach the floor bracket to the end cap of unmovable vertical rail, shown in left drawing(④).




d. Install movable vertical rail


Align the hanger shaft hole with the sliding supporting shaft hole, and insert the bolt into the shaft hole completely(①). Screw the bolt tightly clockwise(②).




e. Untie the cords. Put the buckle bead into groove of headrail end cap (make sure the bead buckle from groove top down) as drawing.




f. Press hangers into headrail from shade front



g. Attach the screw of Floor Bracket into the floor or wall shown below. Floor Bracket has been pre-attached to the end cap of unmovable vertical rail




Into the Floor




Into the Wall

h. If the vertical rail is not perpendicular to the floor, adjustment is necessary.




Not perpendicular



Step 3: How to Install Shade Handle


Slide the handle onto the plastic piece pre-attached to the rails.




Step 4: Remove the shade

Please use the reverse steps of installing vertical rail and shade to remove the vertical rail and shade.

Note: Separate clips from hangers as below drawing, the hangers leave on headrail.





Gently pry the bracket off the head rail with a flat screwdriver as below drawing.




Installation of Extension bracket & spacer block (for OB)

Extension bracket: Allocate a min. distance of $\frac{3}{8}$ " from wall to the bottom of brackets and use screw to secure the bracket. And, use screw to install the Installation bracket on the Extension bracket at $1 \frac{9}{16}$ " (from the wall to the center of the screw bolt) as below pictures.




Spacer block: Install the spacer block (1pc or 2pcs) at the backside of the installation bracket as below pictures. Extend up to 10mm for 1pc spacer block. Extend up to 18mm for 2pcs spacer block.




Spacer block: Install the spacer block (1pc or 2pcs) at the backside of the Floor bracket as below pictures.


Extend up to 10mm for 1pc spacer block. Extend up to 18mm for 2pcs spacer block.



⚠ Extension bracket & Spacer block will be provided only when customer request.

Troubleshooting

Problem	Solution
When the cord is loose, adjustment is necessary. a. Remove the buckle bead from the headrail end cap. b. Remove the cord knot from the buckle, readjust the cord length and tie a knot. Put back the buckle bead into the headrail end cap. Do not over tight.	



N300479-3
65101-11731-C


Installation Instructions

Honeycomb Shades Special Shapes


Perfect Arch




Quarter Round L / R




Elongated Eyebrow




Arch on Top L / R




Eyebrow




Half Eyebrow L/R



Triangle



Angle Top L/R




Step1: Getting Started

Remove the shade from the package. Save the packaging until the shade is installed and working to your satisfaction.

Tools Needed:


- Power drill and drill bit
- Measuring tape
- Screwdriver
- Level
- Pencil



You will need to use the following fasteners for your particular mounting surface.

Surface	Fastener
Wood	#8x1 1/4" Screws (Provide)
	#6x3/4" Screws (Provide)
Drywall/Plaster	Wall Anchors, Expansion Bolts (Not Provide)
Metal	Sheet Metal Screws (Not Provide)

Check Component/Hardware:



for 3/4" S & 1/2" D Installation Bracket for 9/16" S for 3/8" S



Bracket Clip 180° Center Template 90° Center Template



90° Center Support 180° Center Support

Hardware Standard Quantity

For perfect arch, Eyebrow, Elongated Eyebrow, and Triangle:


Order Width (X)	X ≤ 48"	X > 48"
Installation Bracket	2	4
Bracket Clip (for perfect arch, Eyebrow, Elongated Eyebrow)	4	6
Bracket Clip (Triangle)	6	8
1 1/4" Screw for Installation Bracket	Installation bracket qty x 2	
3/4" Screw for Bracket Clip	Bracket Clip qty	

For Quarter Round, Half Eyebrow, Arch on Top, and Angle Top:


Order Width (X)	X ≤ 24"	X > 24"
Installation Bracket	2	4
Bracket Clip (Quarter Round, Half Eyebrow, Arch on Top)	2	4
Bracket Clip (Angle Top)	4	6
1 1/4" Screw for Installation Bracket	Installation bracket qty x 2	
3/4" Screw for Bracket Clip	Bracket Clip qty	

Step2: Assemble the Shade

For Perfect Arch, Eyebrow, Elongated Eyebrow, and Triangle (take Perfect Arch as example): Open the shade and place the rail into the bottom of 180° center support tightly, and then install the front and back 180° center templates:



For Quarter Round, Arch on Top, Angle Top, and Half Eyebrow (take Quarter Round as example): Open the shade and place the rail into the bottom of 90° center support tightly, and then install the front and back 90° center templates:




Step3: Install the Bracket


Mark the bracket location on the mounting surface as shown in the following illustrations.

For Perfect Arch, Eyebrow, Elongated Eyebrow, and Triangle (take Perfect Arch as example):


For shade width X ≤ 48", measure 1.5" (38mm) from both ends of the rail to locate the center of the bracket



For shade width X > 48", place the bracket evenly along the rail




For shade width X ≤ 24", measure 1.5" (38mm) from both ends of the rail to locate the center of the bracket



For shade width X > 24", place the bracket evenly along the rail



Use two #8x1 1/4" screws to attach the installation brackets on the window frame. The min. distance is 11/16" from the front bracket to the edge of window frame.



Step4: Install the Shade

1. Install the Bracket Clip



Insert the Bracket Clip into fabric and then close the Bracket Clip to keep it clamped on the fabric. Double Cell:



Step 1

Step 2



Single Cell:



Step 1



Step 2

Bracket Clip open and close illustration:



For Quarter Round, Arch on Top, Angle Top, and Half Eyebrow (take Quarter Round as example):

2. Put the shade inside the window opening.



3. Install the Screws for Bracket Clip

Mark the bracket clip location on the mounting surface as shown in the following pictures.

Perfect Arch & Eyebrow

Shade width $X \leq 48"$



Shade width $X > 48"$



Elongated Eyebrow

Shade width $X \leq 48"$

Shade width $X > 48"$



⚠ Please pull up the high point of leg (H) to make leg stand before install the Bracket clip screw. The Bracket clip screw should be installed on the curve, not on the leg (H).

Triangle

Shade width $X \leq 48"$



Shade width $X > 48"$



Quarter Round & Half Eyebrow

Shade width $X \leq 24"$



Shade width $X > 24"$



Arch on Top

Shade width $X \leq 24"$

Shade width $X > 24"$





⚠ Please pull up the high point of leg (H) to make leg stand before install the Bracket clip screw. The Bracket clip screw should be installed on the curve, not on the leg (H).

Angle Top

Shade width $X \leq 24"$


Shade width $X > 24"$




Triangle

Shade width $X \leq 48"$

Shade width $X > 48"$



Install a #6x3/4" screw into the corresponding location of the bracket clip about 1 1/8" distance from the front window frame (do not drive the screw completely in and leave around 2mm gap to insert Bracket Clip)




4. Install the rail

Place the front groove of the rail into the front iron wire of the bracket and then push forward to make the back groove of the rail snap into the back groove of the bracket.



Step 1

5. Insert the Bracket Clip into the screw from the notch.





Step 1

Step 2

Remove the Shade

1. Take off the Bracket Clip from the screw.
2. Backward the rail from the front and then force the rail up from the back.



Cleaning


Routine cleaning will help maintain the beauty of your shade. The shade can be cleaned by using a soft brush, vacuumed with a low suction hand-held vacuum, cleaned ultrasonically (specify that a mild

solution must be used and that the head rail should never be immersed in liquid), or dampen a clean cloth with a warm water and mild detergent solution to dab the spot until it's gone (do not rub!).

N300698

65101-11773

Installation Instructions for PVC Light Guard



Install PVC Light Guard (optional for IB)

a. The light guard is to be placed at back of the shade on left & right side.

Place the light guard vertically towards the bottom window frame. To avoid scraping, leave at least 2mm gap between fabric stack and light guard. And then mark out the location with a pencil.

Remove the double sided tapes and carefully paste the light guard in position.

Note: The light guards on both sides are identical;

Use the double-sided tape on the narrow side of the light guard to attach to the window frame.



b. When light guard exceeds certain length, it will be spliced into 2 pieces. We recommend that the seam be placed as close to the fabric stack as possible, shown in below drawings.

